

数量計算書

【土量計算】							
測 点	距 離	堆積厚	幅	断面積	平均断面 積	土 量	摘 要
	(m)	(m)	(m)	(m2)	(m2)	(m3)	
1		0.3	1.2	0.36			
	20				0.34	6.84	
2		0.27	1.2	0.32			
	20				0.30	6.00	
3		0.23	1.2	0.28			
	20				0.26	5.16	
4		0.20	1.2	0.24			
	20				0.22	4.44	
5		0.17	1.2	0.20			
	20				0.18	3.60	
6		0.13	1.2	0.16			
	20				0.14	2.76	
7		0.10	1.2	0.12			
延長	120					28.8	

残土処分土(m3)
28.8